

# Monteringsanvisning för Solskydd

## VW Transporter T5 2003-

To mount this product you will need Sikaflex 252 glue, Sikaflex primer and Sikaflex cleaner (not supplied with the kit).

1. Place the sidebracket on the a-pilar so that the bottom side is 580-585mm from the bottom line of the A-pilar and there is a 13mm gap between innerside of the bracket and the A-pilar as shown on the picture.

2. Mark the hole positions and drill the holes with 4,0 mm bit.

3. Mark the area of the side bracket. Clean the area with cleaner and the backside of the bracket with cleaner.

4. Aply the primer on the cleaned areas and let it react for 15 minutes.

5. Aply Sikaflex 252 on the backside of the side bracket and place it on the a-pilar (atleast 3 wide sripes).

6. Aply Sikaflex 252 into the holes and mount the side-bracket on the pilar with 4,8x19mm screws.

7. Seal the sides of the mounting plate with Sikaflex.

8. Mount the main bracket on the side brackets by using the 8mm washers and nylok nuts.

9. Glue the foam tape on both ends of the main bracket as shown on the picture.

10. Mount the visor on the main bracket according to the drawing.

11. Mount the warning label on a place where the driver can see it. Remember to tighten all screws after few hours drive and every 6 months.

### WARNING!

The speed limit for the vehicle with the visor mounted is 130 km/h. If you drive constantly faster than 130 km/h the visor may tear off!

**ANY NON-COMPLIANCE WITH THESE REGULATIONS CAUSE NO RESPONSIBILITY TO THE MANUFACTURER OF ANY COSTS AND DAMAGES.**

